



Abuse Tolerance Improvement

E. Peter Roth

Sandia National Laboratories

Albuquerque, NM

May 19, 2009



esp_08_roth

This presentation does not contain any
proprietary or confidential information

Sandia is a multiprogram laboratory operated by Sandia Corporation, a Lockheed Martin Company,
for the United States Department of Energy's National Nuclear Security Administration
under contract DE-AC04-94AL85000.



**Sandia
National
Laboratories**



Overview

Timeline

- Start Date: Oct. 2007
- End date: Oct. 2014
- Percent complete: <10%

Budget

- Total project funding
 - \$700K
- FY08 Funding: \$700K
- FY09 Funding: \$700K
- Funding for FY10: TBD

Barriers

- Barriers addressed
 - Develop intrinsically abuse tolerant Li-ion cells and batteries
 - Obtain access to latest promising materials from developers
 - Funding to develop needed expansion and test development

Partners

- ANL, LBNL, BNL, INL



**Sandia
National
Laboratories**



Objectives/Milestones

OBJECTIVES

- Identify degradation mechanisms of gas and heat-producing reactions in lithium ion rechargeable cells.
- Identify and develop advanced materials or combination of materials that will minimize the sources of cell degradation during abuse events, thus enhancing safety.
- Build and test full size cells to demonstrate improved abuse tolerance.

MILESTONES

- Demonstrate improved abuse tolerant cells and report to DOE and the battery community.



Approach


Use Cell Level Abuse Testing to Characterize and Develop Abuse Tolerant Cells

- **Effect of materials on thermal runaway**
 - Use Sandia cell building capabilities to test new anode and cathode materials
 - Electrolytes and additives
- **Overcharge response**
 - Effect of anode and cathode materials on heat and gas generation
- **Separators**
 - Effect of loss of melt integrity
 - High voltage standoff
 - Effect of internal shorts from artificial stimulation



Technical Accomplishments/ Progress/Results

- Quantitatively shown the individual thermal effects of LiMn_2O_4 and LiFePO_4 cell cathode/anode materials in 18650 cells and shown that anode reactions dominate thermal runaway
- Shown by comparative characterization of commercial and research cells with LiFePO_4 cathodes that abuse response normalized by cell capacity is very similar for all cells of this chemistry regardless of manufacturing source or cell design
- Shown gas generation and flammability to be some of the most critical issues for cell level abuse response
- Gas generation during peak runaway normalized by cell capacity has been shown to be independent of cell chemistry and determined primarily by electrolyte quantity



Technical Accomplishments/ Progress/Results (cont.)


- **Shown that cells with LiFePO_4 cathodes, though thermally stable, have higher heat generation during overcharge compared to other cathode oxides and heat generation starts immediately above 100% state of charge resulting from the low cathode Li level at full SOC**
- **Developed new techniques and equipment to study separator integrity and internal cell short circuits by introducing defect particles at the separator layer**
- **Constructed 18650 Cells with fluorinated LiBOB electrolyte additive and shown them to have reduced thermal reactions during high temperature abuse testing**



Thermal Runaway Cathode Comparisons

Improved Cathode Stability Results in
Increased Thermal Runaway Temperature
And Reduced Peak Heating Rate for Full Cell

Decreased Cathode Reactions
Associated with Decreasing
Oxygen Release



EC:PC:DMC
1.2M LiPF₆

ARC

100% SOC




Sandia
National
Laboratories

ARC Profile LiFePO_4 : Full Cell and Cathode Electrode\Electrolyte


Cathode\Electrolyte

HQ Cell #3: LiFePO_4 0.9 Ah



Full Cell
Cathode\Electrolyte

HQ Cell\Cathode: LiFePO_4





**Anode Reactions
Dominate Cell Response**

LiFePO₄ Cells Show Lower Reaction Kinetics and Reaction Enthalpy Compared to LiMn₂O₄ Cells

LiFePO₄ Does Not Release Oxygen and Shows the Lowest Thermal Reactions

Different Source LiFePO₄ Cells Show Similar Onset Thermal Response Which Are Greatly Reduced Compared to Layered Ni Oxides





Commercial Cells "X" and "Y"
Cell "Z" built at Sandia



Sandia
National
Laboratories

Gas Evolution is a Critical Property Affecting Safety

Gas Evolution Begins ~ 150°C from Electrolyte Decomposition
Gas Evolution During Peak Runaway Has Greatest Safety Impact




1.2 Ah MCMB/LiCoO₂ EC:PC:DMC/1.2M LiPF₆



Sandia
National
Laboratories


Gas Evolution for Different Cathode Chemistries

Peak Gas Evolution Independent of Cathode Chemistry
Determined by Quantity of Electrolyte



Thermal Ramp Apparatus

Ramp to runaway in air with external ignition



Ramp at 6 °C/min

190 °C

Thermal Block

Cell TC

Block TC

Cell Voltage
Leads

Heater Cartridge

Insulated
Cell

Copper
Block



Heat Block with External Ignition Sources
Cell has vented and is about to enter
explosive decomposition stage.





Sandia
National
Laboratories

Comparison of Commercial LiFePO_4 Cells with LiMn_2O_4 Cell

Cell Thermal Response Scales
With Capacity as Expected

Normalized Cell Response
Very Similar for Different Cell Capacities




26650 Cells



Cells Remained Intact
During Thermal Runaway

Reduced High-Temperature Thermal Reactions with Fluorinated LiBOB Additives

**Addition of 3% $\text{LiC}_2\text{O}_4\text{BF}_2$
Reduces Low Temperature and
High Temperature Reactions
with No Increase in Gassing**



Overcharge Response



- **Overcharge is one of the most energetic abuse conditions**
 - Highly reactive, unstable cathode
 - Highly lithiated anode
- **High levels of heat generation**
 - Separator shutdown and possible internal short
 - Initiation of thermal decomposition runaway
- **Flammable gas generation**
 - Hydrogen
 - Venting of solvent vapors



LiFePO₄ Cells Show Greater Heating During Overcharge Compared to Other Cathode Oxides

Heat Generation Begins Immediately On Overcharge of LiFePO₄ Cells



Heat Generation Begins When Li Has Been Removed From Cathode




1C Overcharge

Induced Internal Shorts

Internal shorts have been induced in coin cells and full 18650 cells using defect particles and external stimulation



Cell with Ni particles:
Ramp to 135°C then short





Sandia
National
Laboratories

Separator Failure Characterization

Shutdown temperature is well defined.

Shutdown integrity affected by pressure and surface irregularities

Upgraded separator characterization apparatus with programmable load fixture to test for pressure induced separator failures with and without defect particles





Future Work

Emphasis On New PHEV, High Energy Density Materials

- **Develop an enhanced stability cell by conducting quantitative cell-level abuse studies to verify material enhancements (e.g. AlF_3 coated NMC cathodes).**
- **Demonstrate improved overcharge abuse tolerance in full cells with new materials and additives.**
- **Demonstrate reduced electrolyte gas generation under full-cell abuse conditions using non- PF_6 salts with increased temperature and voltage stability.**
- **Support development of an abuse model using measured cell material properties that will allow prediction of cell abuse response for any given cell design and failure mode (e.g. internal short).**



**Sandia
National
Laboratories**



Summary

- Increased thermal stability has been demonstrated with more stable cathodes (LiMn_2O_4 Spinel and LiFePO_4)
 - Improved stability results from decreased oxygen generation
- Anode reactions are still important to provide better abuse tolerance
- Certain additives can reduce thermal reactions under abuse conditions
- Electrolyte gas generation and flammability still a critical issue
- Separator integrity is a critical to cell abuse tolerance and safe operation